





ENJOY WATER®

38 562





Modellnummer	X1	X2
38 541, 38 546, 38 554, 38 555, 38 557	646-1070	455-755
38 516, 38 522, 38 523	650-1070	460-755
38 515	675-1070	475-755
38 513, 38 514, 38 521	795-1070	560-755
38 528, 38 531, 38 536, 38 539, 38 593, 38 624, 38 721, 38 722, 38 728, 38 750, 38 763, 38 764	700-1070	495-755
38 525, 38 526, 38 618, 38 622, 38 591, 38 761	780-1070	550-755

